



BUTTON OPERATION

- A** SET
- B** MODE
- C** ADJUST, START/STOP
- D** LIGHT

E-02)



- E-14)

- E-15

1. Standard display mode: Hour, Minutes, Seconds, Month, Day of the week.
2. Function:
 - * Month, Date AM/PM and Electro-Luminescent light.
 - * Alarm function with buzzer signal output.
 - * Chronograph function with lap operation.
 - * Hourly chime.
 - * 12/24 hour format switch option.
 - * Timer.
 - * Second time zone.
3. Accuracy at normal temperature (25 °C): ± 30 seconds a month.
4. Normal operating temperature range: 10°C ~ 40°C.
5. Battery: □ CR2016 □ CR1620 □ CR2025 □ CR2032